

## **ASSEMBLING OF BED**

### **INSTRUCTIONS**

1. When fixing the side-rail to footboard or headboard make sure that:
  - a) the side-rail is properly held so that the 2 dowels and the middle bolt are completely pushed into the holes.
  - b) The central bolt is tightened before moving the headboard or footboard.

**IMPORTANT:** when fixing the side rails to headboard and footboard do not tighten too much otherwise the panel will be damaged. Use metal brackets to fix everything properly.
2. Fix the 4 metal brackets (see drawing) using the self-threading screws (there are no holes on the panel) included in the hardware.

**IF YOU DON'T COMPLY WITH ABOVE INSTRUCTIONS THE SIDE-RAILS  
MAY COME OFF THE PANEL AND BREAK IT!**

